

Fondo FDA Medio

Description	White undercoat with high opacity for Firma d'Autore decorative cycles INTERIOR
Support surface	Traditional or pre-mixed plaster, gypsum boards
Composition	Water dispersion with organic ligand
Technical Characteristics	
Aspect	Matt
Specific Weight	1,50 ± 0,03 Kg/L
pH	8,5
Yield	8-10 m ² /L for each coat
Dry to touch	2-3 h at 20 °C RU 60%
Recoating	3-4 h at 20 °C RU 60%
Application	
Environmental conditions	T. min 5 °C T.max 30 °C R.U. 60%
Tools	Medium pile roll
Dilution	Ready to use
Colours	White
Advices	Always apply in the recommended condition. Verify the support status before beginning and check that the surfaces is clean, dry and with uniform absorption. For smooth plaster, for lime surfaces and for particularly powdery surfaces a first coat of Primer FDA is required. Diluted 1:5 with water and applied with brush.

APPLICATION OF Fondo FDA Medio:

After carefully clearing and filling the imperfection of the support surface, apply Fondo FDA Medio using medium pile roll.

Packaging:

Fondo FDA Medio: 12,5, 5,0, 2,5 and 1,0 Lt

Storage: Minimum Temperature: 5 °C

Maximum Temperature: 30 °C

Waste treatment methods:

Empty Can: special waste similar to urban waste

Can with residue: special waste

Stability:

360 days in the original cans.

F.D.A. s.r.l.

24043 Caravaggio / BG

Via Piave,1

Tel. e Fax +39 035 578 51 39 info@firmadautore.it

The above technical information is the result of accurate laboratory tests and practical experience. However, given that the product is often used without our control, we cannot but guarantee its quality. This information is subject to possible updates by the company.