

## Fondo FDA Fine

Description	White undercoat with high opacity for Firma d'Autore decorative cycles INTERIOR
Support surface	Traditional or pre-mixed plaster, gypsum boards
Composition	Water dispersion with organic ligand
	Technical Characteristics
Aspect	Matt
Specific Weight	1,50 ± 0,03 Kg/L
рН	8,5
Yield	8-10 m <sup>2</sup> /L for each coat
Dry to touch	2-3 h at 20 °C RU 60%
Recaoting	3-4 h at 20 °C RU 60%
	Application
Environmental conditions	T. min 5 °C T.max 30 °C R.U. 60%
Tools	Medium pile roll
Dilution	Ready to use
Colours	White and colour of Galassie FDA colour chart
Advices	Always apply in the recommended condition. Verify the support status before beginning and check that the surfaces is clean, dry and with uniform absorption. For smooth plaster for lime surfaces and for particularly powdery surfaces a first coat of Primer FDA is required. Diluted 1:5 with water and applied with brush.

## APPLICATION OF Fondo FDA Fine:

After carefully clearing and filling the imperfection of the support surface, apply Fondo FDA Fine using medium pile roll.

Packaging:

Fondo FDA Fine: 12,5, 5,0, 2,5 and 1,0 Lt

Storage: Minimum Temperature: 5 °C

Maximum Temperature: 30 °C

Waste treatment methods:

Empty Can: special waste similar to urban waste

Can with residue: special waste

Stability:

360 days in the original cans.