

Fondo Metallico FDA

Description	Acrylic undercoat finishes INTERIOR
Support surface	Traditional or pre-mixed plaster, gypsum boards
Composition	Water dispersion with organic ligand
Technical Characteristics	
Specific Weight	1,50 ± 0,03 Kg/L
pH	8,5
Yield	5-6 m ² /L for each coat
Dry to touch	3-2 h at 20 °C RU 60%
Recoating	4-5 h at 20 °C RU 60%
Application	
Environmental conditions	T. min 5 °C T.max 30 °C R.U. 60%
Tools	Brush
Dilution	15% with water
Colours	Black
Advices	Always apply in the recommended condition. Verify the support status before beginning and check that the surfaces is clean, dry and with uniform absorption. Apply a coat of Fondo FDA Fine.

APPLICATION FERRO EFFETTO RUGGINE:

On the surface previously treated with Fondo FDA Fine, spread a coat of Fondo Metallico FDA using a brush, taking care to distribute the product not in a uniform way, creating areas with more product that determine the final decorative effect. When Fondo Metallico FDA is completely dry (after 4-5 hours) apply on the surface, using a brush, Ruggine FDA. Distribute the product with a steel, taking care to highlight the areas with more Fondo Metallico FDA. A second coat of Ruggine FDA may be applied depending on the desired effect.

Packaging:

Fondo Metallico FDA: 2,5 and 1,0 Lt

Storage: Minimum Temperature: 5 °C

Maximum Temperature: 30 °C

Waste treatment methods:

Empty Can: special waste similar to urban waste

Can with residue: special waste

Stability:

360 days in the original cans.

F.D.A. s.r.l.

24043 Caravaggio / BG

Via Piave,1

Tel. e Fax +39 035 578 51 39 info@firmadautore.it

The above technical information is the result of accurate laboratory tests and practical experience. However, given that the product is often used without our control, we cannot but guarantee its quality. This information is subject to possible updates by the company.