

Metallo d'Autore

Description	Metal-based micro-coating for
	INTERIORS
Substrates	All types of plasters, pre-painted walls, and concrete
Composition	BASE: aqueous dispersion in organic binder
	METAL POWDER: to be blended into the BASE just before application
	Technical Characteristics
Density	BASE: 1.01 ± 0.03 Kg/L
рН	8.5
Yield	1.4-1.6 m ² /Kg in two coats
Drying	10 h at 20°C, RH 60%
	Application
Environmental Conditions	T. min 5°C, T. max 30°C, R.H. 60%
Tools	Stainless steel trowel
Dilution	Blend the METAL into the BASE (1:1)
Powder Types	Zinco, Stagno, Bronzo, Ottone
Precautions	Always apply under the conditions indicated. Check the condition of the substrate before
	starting and ensure that the surface is clean, dry, and uniform in absorption and
	appearance. Apply one coat of Fondo FDA Fine.

APPLICATION OF METALLO D'AUTORE:

Mix the POWDER (of the chosen type) into the BASE by stirring carefully for at least 5 minutes, until completely blended. Apply a first coat of product evenly, but not too thickly, over the entire surface using a stainless steel trowel, and leave to dry for at least 4-5 hours. Apply a second coat of reconstituted product, again with a stainless steel trowel over the entire surface, but unevenly. After at least 24 hours, proceed to polish the applied surface using sandpaper of varying grits (preferably of silicon carbide); the recommended order of the grits used is: 320, 800, 1200, and lastly 2000 or 3000. Continue polishing until the desired effect is achieved.

Packages:

Base: 1 Kg, 4 Kg

Metal Powder: 1 Kg, 4 Kg

Storage: Minimum temperature: 5°C

Maximum temperature: 30°C

Stability:

3 years in the original containers

Recommendations for disposal: Code(s) of the European Waste Catalogue (Decision 2014/955/EU) 15 01 2. The EWC code given is only a general indication based on the product's original composition and envisaged use. It is the ultimate responsibility of the user to choose the most appropriate EWC code, based on the actual use of the product and on any alteration or contamination that may have occurred.

F.D.A. s.r.l.
Via Piave, 1
24043 Caravaggio (BG)
Tel. & Fax +39 035 578 51 39 / info@firmadautore.it

The technical information provided above is the result of careful laboratory testing and practical experience. Nevertheless, as the product is often used outside our control, we can only guarantee its quality. This information is subject to possible updates by the company.