

## Satin

Description	Decorative shiny finishing with satin effect INTERIOR
Support surface	Traditional or pre-mixed plaster, gypsum boards
Composition	Water dispersion with organic binder and pearlescent pigment
	Technical Characteristics
Specific Weight	1,1 ± 0,03 Kg/L
рН	8,5
Yield	10/12 m <sup>2</sup> /L for each coat
Dry to touch	3-4 h at 20 °C RU 60%
	Application
Environmental conditions	T. min 5 °C T.max 30 °C R.U. 60%
Tools	Spalter or Sponge
Dilution	Ready to Use
Colours	Colour chart Satin & Satin Soft Firma d'Autore
Advices	Always apply in the recommended condition. Verify the support status before beginning and check that the surfaces is clean, dry and with uniform absorption. Before apply one coat of Fondo FDA Fine.

## APPLICATION OF SATIN with brush:

Apply SATIN in irregular cross brush strokes across the surface which has been previously prepared using Fondo FDA fine or Fondo FDA medio. It is important to avoid distinct rectangular patterns. When the first coat is dry after 4-6 hours apply a second coat in the same way. In order to obtain a softer-edge effect and to render the distribution of the product more homogeneous, go over the surface again with a dry brush. The quantity of the material used, the dimensions of the surface, the form and intensity of the brush strokes all determine the personalized decorative effect achieved.

## APPLICATION OF SATIN with sponge:

Apply Satin with circular motion, sometimes changing the direction, on the surfaces which has been previously prepared using Fondo FDA fine or Fondo FDA medio. Distribute the product homogeneously avoiding accumulations of material. When the first coat is dry after 4-6 hours apply a second coat in the same way.

Packaging:

Satin: 5,0 Lt, 2,5 Lt and 1,0 Lt

## Waste treatment methods:

Empty Can: special waste similar to urban waste

Can with residue: special waste  $\label{eq:Storage:Minimum Temperature: 5 °C}$ 

Maximum Temperature: 30 °C

Stability:

360 days in the original cans.

F.D.A. s.r.l. 24043 Caravaggio / BG Via Piave,1 Tel. e Fax +39 035 578 51 39 <u>info@firmadautore.it</u> The above technical information is the result of accurate laboratory tests and practical experience. However, given that the product is often used without our control, we cannot but guarantee its quality. This information is subject to possible updates by the company.